


## STRAIGHT THROUGH BASE



### PRODUCT DESCRIPTION

Chamber base have sockets type Eurosocket for connection with smooth-wall pipe or Pragma type for structural pipes Pragma. For Pragma pipe connection with socket type Eurosocket Pragma Ecc Adaptor should be used. For smooth-wall pipe connection with socket Pragma type stabilize click ring and sealing ring should be used.

| SAP Index  | SAP material description                          | Outlet type | BUoM |
|------------|---|-------------|------|
| 3496101297 | OS Base 1000 0°/180° dim160                       | Smooth pipe | EA   |
| 3496101298 | OS Base 1000 0°/180° dim200                       | Smooth pipe | EA   |
| 3496101299 | OS Base 1000 0°/180° dim250                       | Smooth pipe | EA   |
| 3496101300 | OS Base 1000 0°/180° dim315                       | Smooth pipe | EA   |
| 3496101301 | OS Base 1000 0°/180° dim400                       | Smooth pipe | EA   |
| 3496102449 | OS Base 1000 0°/90°/0°/270° bend dim l250 or r250 | Smooth pipe | EA   |
| 3496102453 | OS Base 1000 0°/90°/0°/270° bend dim l315 or r315 | Smooth pipe | EA   |